



CLEANING INSTRUCTION FOR EXPANDED BEAM TECHNOLOGY



CLEANING SET ORDER NO. 50296834

consists of

- 1 pc. Cleaning alcohol 80 ml
- 50 pcs. Cleaning sticks
- 1 pc. Cleaning instruction

CLEANING ALCOHOL

Highly flammable liquid and vapour. Causes serious eye irritation. May cause drowsiness or dizziness. Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking. Ground / bond container and receiving equipment. Wear protective gloves / protective clothing / eye protection / face protection.

IF INHALED: Remove person to fresh air and keep comfortable for breathing.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

Dispose of contents / container in accordance with local / regional / national / international regulations. Material safety data sheet on

www.odu-connectors.com

STEP BY STEP INSTRUCTION

CLEANING MUST BE DONE AFTER EVERY 20,000 MATING CYCLES.



1 Moisten cleaning sticks with cleaning alcohol.



4 Insert cleaning stick into the receptacle and place it on the lens.



2 Insert cleaning stick into the connector and place it on the lens.



5 Clean lens with cleaning stick by turning it.



3 Clean lens with cleaning stick by turning it.

TO ORDER THE CLEANING ACCESSORIES SEPARATELY:

**CLEANING ALCOHOL:
ORDER NO. 50295857**

**5 CLEANING STICKS Ø 2.0:
ORDER NO. 50294688**

All dimensions are in mm. Some figures are for illustrative purposes only. Subject to change without notice. Errors and omissions excepted. We reserve the right to change our products and their technical specifications at any time in the interest of technical improvement. This publication supersedes all prior publications. This publication is also available as a PDF file that can be downloaded from www.odu-connectors.com

IMPORTANT NOTES

Always clean both sides of the connector and if disconnected also clean the standard fiber optic connectors on the other side of the connection system (with a standard ferrule cleaning procedure).

CLEANING INSTRUCTION FIBER OPTIC EBT / IT / 0221 / EN

